




MR FOX IN A BOX
PREMIUM GARDEN FURNITURE

PART LIST

1X LEFT SIDE
1X RIGHT SIDE
1X FRONT PANEL
1X BACK PANEL
1X BOLT KIT
1X WICKING SYSTEM

4 & 5-CELL ONLY
1X CENTRE LEG
1X CENTRE SUPPORT RAIL



1
LAY SIDE A ON GROUND USE
CARDBOARD BOX UNDER SO YOU
DONT THE MARK SIDES

2



ATTACH PANEL A TO SIDE A WITH WINGNUTS
TO EXSISTING TOP & BOTTOM BOLTS. ATTACH
BACK PANEL WITH WINGNUTS TO EXSISTING
TOP & BOTTOM BOLTS

NOTE ONLY ON 4 & 5 CELLS ATTACH
CENTRE BOTTOM RAIL WITH BOLTS AND
WINGNUT

3



STAND UP AND SIT OTHER END ON
THE OPPOSITE SIDE

4



STAND OPPOSITE SIDE UP SLOWLY
HOLDING THE TOP OF EACH PANEL IN SO
THE SIDE SLIDES INTO PLACE. ATTACH
WINGNUTS TO TOP AND BOTTOM BOLTS

5



SLIDE BOLTS THROUGH CENTRE
HOLES ON FRONT & BACK LEG,
ATTACH WITH WINGNUT & TIGHTEN
ALL WINGNUT

6

NOTE ATTACH CENTRE SUPPORT
LEG ON 4 & 5 CELLS MODELS ONLY

7

FIT WICKING SYSTEM IN AS PER
INSTRUCTIONS

